TOYOTA

Other Mongoose / Toyota CanBus Products

TVSR - Voice Safety Reminder System and Speed Alert

The TVSR gives you voice warnings such as; if any door is left open, the handbrake is on, you haven't put your seat belt on -10 different vehicle modes are monitored. It also includes an over-speed warning which you can set.

TES – Remote Engine Starter

Cool dow n your cars interior in summer or w arm it up in winter. Just press your Toyota remote buttons to start the engine before you enter the car. Foolproof and safe.

TTP - GSM Alarm text pager

Afraid you wont hear your car alarm sound ? Did you lock the doors ? Fear not, the TTP sends a warning text message if the alarm sounds and you can text the car to check if it is locked – if not, send another text to lock it !

TWK – Window wind-up

Found that a window has been left open after you have locked it? Just press your Toyota remote to wind up any open windows. A bit too hot in summer to get in ? Just press your remote to open all or just one window to cool down.

www.mongoose.com.au

www.mongoose.co.nz

Specifications may change without prior notification We advise professional fitting of this product.





'TA' Vehicle Security System

Suitable for 2009/2010 models onwards AURION CAMRY COROLLA PRIUS PREVIA YARIS HIGHLANDER LANDC RUISER 200 PRADO RAV4

Installation & Operation

CanBus data communication

'TA' Toyota CANBUS Vehicle Security Alarm System

This product is an advanced digital signal, microprocessor controlled alarm system that is designed to work with Toyota's passenger vehicles Canbus kevless entry system.

Instruction for use:

1/ The TA system will arm and disarm at the same time the vehicle locks or unlocks from the Toyota remote control. The siren chirps to confirm operation.

2/ An intrusion through any of the doors, tailgate/boot or bonnet will trigger the alarm system.

3/ Glass breakage is detected by the microphone sensor and will trigger the alarm if it 'hears' the sound of glass breaking. The sensor is adjustable for sensitivity.

4/ Ignition door lock & unlock. (Optional connection)

If connected, the TA will lock the doors when driving speed exceeds 15kph. Doors automatically unlock when the ignition is turned off.

5/ If the alarm is armed by original remote but unlocked by some other remote. this will be treated as unauthorized intrusion and will trigger the alarm.

6/ The supplied siren is a battery back-up type. Battery isolating keys are supplied to disable the siren during routine servicing, a vehicle fault causes the siren to sound when it shouldn't or when the vehicle battery is to be disconnected.



Installation of components









- Locate ODBII canbus connector under the steering wheel lower dash area (Fig A)
- Plug in supplied OBDII wiring harness (Fig B) Note: make sure the two connectors are firmly connected. Secure harness with cable ties.
- Fit the female connector of ODDII harness into original OBD socket location (Fig C) (Colours of plugs may differ)
- Attach the glass break sensor module with cable ties under the dashboard in a position where it can be adjusted. Mount the microphone to the top or bottom of the 'A' pillar. Carefully route the cable to avoid any airbags.
 - Mount the siren under the bonnet near the vehicle battery or other suitable location which avoids excessive heat and possible water penetration but allows the sirens internal battery isolating key access. Connect siren ground with a star washer direct to the vehicle chassis - not any siren mounting screw. Fit a ring terminal onto the +12v (red) and connect to the vehicle battery.
- Fit the supplied bonnet pin switch and parallel the trigger wire to the siren wires.
- 7. Run the siren and bonnet trigger wires through an existing firewall rubber grommet and connect to the modules siren wire.
 - Plug in the glass break sensor and siren harness. (Fig D) Connect bonnet trigger wire to white of glass sensor loom. Plug in the CanBus ODBII connector. Connect black/white wire (-) to hazard switch
 - Test for correct operation. If necessary, adjust the sensor for correct sensitivity.
- Note: The control module must be concealed from tampering. Secure the unit in chosen location.

IMPORTANT

If connecting more than one Toyota control unit, the second unit does not require the main 'T' OBDII connector - use the supplied 3 wire interconnect loom. If a 'TWK' window kit is also used, the window kit must be last in series. Do not use two OBDII Canbus looms.



for interconnect

