



Step 1

- Remove the carpet and interior trim panels.
- Remove the spare wheel and tools.
- Be careful not to break any door trim fittings.
- Make notes or take photographs of how parts fit so re-assembly is made easier.
- Keep all screws and fasteners together in a container.



Step 2

- Vacuum the boot floor and thoroughly clean the surface to which the Q-Mat is to be applied.
- Installation must be carried out the surface is dry and contaminant free.



Step 3

- Cut the Q-Mat to the desired size and shape with a sharp blade knife or scissors.
- Remove the backing paper and press the Q-Mat firmly to ensure the material sticks firmly onto the surface.
- A heat gun can be used to make the Q-Mat more pliable and a roller to iron out any wrinkles.



Step 4

- Cover all panels where practical. Allow access to drainage rubber plugs in the floor
- Butt the edges of the Q-Mat together
- Re-fit the spare wheel & tools.
- Refit the boot trim panels and floor carpet.